3 Easy Steps to Set Up Your Wind Spinner







STEP 1:

Remove wind spinner from the box. Hold the wind spinner in both hands with your right hand at the top near the hook and left hand at the bottom.

STEP 2:

Position your thumbs on the innermost ring just to the left of the center spine and push away from you. The wind spinner should fan open by itself.

STEP 3:

Continue until there is about half an inch between each ring as pictured. Adjust individual rings as needed.